

## **PUSH PAD**

The single hinged door can be equipped with a Euro Cylinder knob lock with a push pad panic exit device mounted on the inside of the door blade. The door is kept locked from the outside and you will need a key to open, while it's always safe to escpae from the inside, just push the panic device and the door will open.

The Push Pad JPM solution is easily assembled and attaced to the door blade with special fixings. The Push Pad lock is CE marked, tested and approved according to EN 179 for emergency exit devices.



## **FACTS**

| ART. NO  | COMPONENTS            |
|----------|-----------------------|
| 36905470 | Kit 5470 Push Pad JPM |



## **IMAGES**





